



MANUAL

Serie Rack Online

PH 9310 · 1000 VA / PH 9315 · 1500 VA
PH 9320 · 2000 VA / PH 9330 · 3000 VA



www.phasak.com

1. Important Safety Warning	38
1.1. Transportation	38
1.2. Preparation	38
1.3. Installation	38
1.4. Operations	38
1.5. Maintenance, service and faults	38
2. Installation and setup	39
2.1. Rear panel view	39
2.2. Rack-mounted the UPS	39
2.3. Setup the UPS	39
2.4. Battery replacement	41
2.5. Battery kit assembly (option)	42
3. Operations	43
3.1. Button operation	43
3.2. LCD Panel	44
3.3. Audible Alarm	45
3.4. LCD display wordings index	45
3.5. UPS Setting	46
3.6. Operating Mode Description	49
3.7. Faults Reference Code	50
3.8. Warning indicator	50
4. Troubleshooting	51
5. Storage and Maintenance	53
6. Specifications	54

EN 1. Important Safety Warning

Please comply with all warnings and operating instructions in this manual strictly. Save this manual properly and read carefully the following instructions before installing the unit. Do not operate this unit before reading through all safety information and operating instructions carefully.

1.1. Transportation

- Please transport the UPS system only in the original package to protect against shock and impact.

1.2. Preparation

- Condensation may occur if the UPS system is moved directly from cold to warm environment. The UPS system must be absolutely dry before being installed. Please allow at least two hours for the UPS system to acclimate the environment.
- Do not install the UPS system near water or in moist environments.
- Do not install the UPS system where it would be exposed to direct sunlight or near heater.
- Do not block ventilation holes in the UPS housing.

1.3. Installation

- Do not connect appliances or devices which would overload the UPS system (e.g. laser printers) to the UPS output sockets.
- Place cables in such a way that no one can step on or trip over them.
- Do not connect domestic appliances such as hair dryers to UPS output sockets.
- The UPS can be operated by any individuals with no previous experience.
- Connect the UPS system only to an earthed shockproof outlet which must be easily accessible and close to the UPS system.
- Please use only VDE-tested, CE-marked mains cable (e.g. the mains cable of your computer) to connect the UPS system to the building wiring outlet (shockproof outlet).
- Please use only VDE-tested, CE-marked power cables to connect the loads to the UPS system.
- When installing the equipment, it should ensure that the sum of the leakage current of the UPS and the connected devices does not exceed 3.5mA.

1.4. Operation


- Do not disconnect the mains cable on the UPS system or the building wiring outlet (shockproof socket outlet) during operations since this would cancel the protective earthing of the UPS system and of all connected loads.
- The UPS system features its own, internal current source (batteries). The UPS output sockets or output terminals block may be electrically live even if the UPS system is not connected to the building wiring outlet.
- In order to fully disconnect the UPS system, first press the OFF/Enter button to disconnect the mains.
- Prevent no fluids or other foreign objects from inside of the UPS system.

1.5. Maintenance, service and faults

- The UPS system operates with hazardous voltages. Repairs may be carried out only by qualified maintenance personnel.
- **Caution** - risk of electric shock. Even after the unit is disconnected from the mains (building wiring outlet), components inside the UPS system are still connected to the battery and electrically live and dangerous.
- Before carrying out any kind of service and/or maintenance, disconnect the batteries and verify that no current is present and no hazardous voltage exists in the terminals of high capability capacitor such as BUS-capacitors.
- Only persons are adequately familiar with batteries and with the required precautionary measures may replace batteries and supervise operations. Unauthorized persons must be kept well away from the batteries.
- **Caution** - risk of electric shock. The battery circuit is not isolated from the input voltage. Hazardous voltages may occur between the battery terminals and the ground. Before touching, please verify that no voltage is present!
- Batteries may cause electric shock and have a high short-circuit current. Please take the precautionary measures specified below and any other measures necessary when working with batteries:
 - › remove wristwatches, rings and other metal objects.
 - › use only tools with insulated grips and handles.
- When changing batteries, install the same number and same type of batteries.
- Do not attempt to dispose of batteries by burning them. This could cause battery explosion.
- Do not open or destroy batteries. Escaping electrolyte can cause injury to the skin and eyes. It may be toxic.
- Please replace the fuse only with the same type and amperage in order to avoid fire hazards.
- Do not dismantle the UPS system.

NOTE: Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. Please keep the original package in a safe place for future use.

2.1. Rear panel view



PH 9310 (1K) | PH 9315 (1,5K) | PH 9320 (2K)


PH 9330 (3K)

- 1. Programmable outlets: connect to non-critical loads | 2. Output receptacles: connect to mission-critical loads
- 3. AC input | 4. Input circuit breaker | 5. Network/Fax/Modem surge protection | 6. Emergency power off function connector (EPO) | 7. USB communication port | 8. RS-232 communication port | 9. SNMP intelligent slot
- 10. External battery connection (depends on the model)


2.2. Rack-Mounted the UPS

This UPS can be mounted in the 19" rack chassis. Please follow below steps to position this UPS.

Step 1



Step 2




2.3. Setup the UPS

Step 1: Connect battery wires

- For safety consideration, the UPS is shipped out from factory without connecting battery wires. Before install the UPS, please follow below steps to re-connect battery wires first.

Step 1




Remove front panel.

Step 2



Connect the AC input and re-connect battery wires.

Step 3



Put the front panel back to the unit.

Step 2: UPS input connection

- Plug the UPS into a two-pole, three-wire, grounded receptacle only. Avoid using extension cords.
- For 208/220/230/240VAC models: The power cord is supplied in the UPS package.

Note: For Low voltage models: Check if the site wiring fault indicator lights up in LCD panel. It will be illuminated when the UPS is plugged into an improperly wired utility power outlet (Refer to Troubleshooting section).

Step 3: UPS output connection


- For socket-type outputs, there two kinds of outputs: programmable outlets and general outlets. Please connect noncritical devices to the programmable outlets and critical devices to the general outlets. During power failure, you may extend the backup time to critical devices by setting shorter backup time for non-critical devices.
- For terminal-type input or outputs on the **3K UPS**, please follow below steps for the wiring configuration:
 - a) Remove the small cover of the terminal block.
 - b) Suggest using AWG14 or 2.1mm² power cords.
 - c) Upon completion of the wiring configuration, please check whether the wires are securely affixed.
 - d) Put the small cover back to the rear panel.

Step 3: Communication connection (varies depending on the model) Communication port:

USB Port



RS-232 Port



Intelligent Slot



To allow for unattended UPS shutdown/start-up and status monitoring, connect the communication cable one end to the USB/RS-232 port and the other to the communication port of your PC. With the monitoring software installed, you can schedule UPS shutdown/start-up and monitor UPS status through PC.


The UPS is equipped with intelligent slot perfect for either SNMP or AS400 card. When installing either SNMP or AS400 card in the UPS, it will provide advanced communication and monitoring options. Note. USB port and RS-232 port can't work at the same time.

Step 4: Network connection (varies depending on the model) Network/Fax/Phone surge ports



Step 5: Disable and enable EPO function (varies depending on the model)

Keep the pin 1 and pin 2 closed for UPS normal operation. To activate EPO function, cut the wire between pin 1 and pin 2.



Step 6: Turn on the UPS

Press the ON/Mute button on the front panel for two seconds to power on the UPS.

Note: The battery charges fully during the first five hours of normal operation. Do not expect full battery run capability during this initial charge period.


Step 7: Install software

For optimal computer system protection, install UPS monitoring software to fully configure UPS shutdown. You may insert provided CD into CD-ROM to install the monitoring software. If not, please follow steps below to download and install monitoring software from the internet:

1. Go to the website <http://www.phasak.com/descargas>
2. Click ViewPower software icon and then choose your required OS to download the software.
3. Follow the on-screen instructions to install the software.
4. When your computer restarts, the monitoring software will appear as an orange plug icon located in the system tray, near the clock.

Step 8: External battery connection

Follow below chart to make external battery connection:




2.4. Battery replacement

Notice: This UPS is equipped with internal batteries and user can replace the batteries without shutting down the UPS or connected loads.(hot-swappable battery design) Replacement is a safe procedure, isolated from electrical hazards.


CAUTION!! Consider all warnings, cautions, and notes before replacing batteries.
Note: Upon battery disconnection, equipment is not protected from power outages.

Step 1




Remove front panel.

Step 2




Disconnect battery wires.

Step 3




Pull out the battery box by removing two screws on the front panel.

Step 4




Remove the top cover of battery box and replace the inside batteries.

Step 5




After replacing the batteries, put the battery box back to original location and screw it tightly.

Step 6



Re-connect the battery wires.

Step 7




Put the front panel back to the unit.

2.5. Battery kit assembly (optional)

Notice: Please assemble battery kit first before installing it inside of UPS. Please select correct battery kit procedure below to assemble it.


2-battery kit:

Step 1




Remove adhesive tapes.

Step 2




Connect all battery terminals by following upper chart.

Step 3



Put assembled battery packs on one side of plastic shells and insert one more defect battery on the space.


Step 4



Cover the other side of plastic shell as below chart. Then, battery kit is assembly well.


4-battery kit:

Step 1




Remove adhesive tapes.

Step 2



Connect all battery terminals by following upper chart.

Step 3



Put assembled battery packs on one side of plastic shells.


Step 4



Cover the other side of plastic shell as below chart. Then, battery kit is assembly well.


6-battery kit:

Step 1




Remove adhesive tapes.

Step 2




Connect all battery terminals by following upper chart.

Step 3



Put assembled battery packs on one side of plastic shells.

Step 4




Cover the other side of plastic shell as below chart. Then, battery kit is assembly well.











3.1. Button operation

Button	Function
ON/Mute Button	<ul style="list-style-type: none"> • Turn on the UPS: Press and hold ON/Mute button for at least 2 seconds to turn on the UPS. • Mute the alarm: When the UPS is on battery mode, press and hold this button for at least 5 seconds to disable or enable the alarm system. But it's not applied to the situations when warnings or errors occur. • Up key: Press this button to display previous selection in UPS setting mode. • Switch to UPS self-test mode: Press ON/Mute buttons simultaneously for 5 seconds to enter UPS self-testing while in AC mode, ECO mode, or converter mode.
OFF/Enter Button	<ul style="list-style-type: none"> • Turn off the UPS: Press and hold this button at least 2 seconds to turn off the UPS in battery mode. UPS will be in standby mode under power normal or transfer to Bypass mode if the Bypass enable setting by pressing this button. • Confirm selection key: Press this button to confirm selection in UPS setting mode.
Select Button	<ul style="list-style-type: none"> • Switch LCD message: Press this button to change the LCD message for input voltage, input frequency, battery voltage, output voltage and output frequency. It will return back to default display when pausing for 10 seconds. • Setting mode: Press and hold this button for 5 seconds to enter UPS setting mode when UPS is in standby mode or bypass mode. • Down key: Press this button to display next selection in UPS setting mode.
ON/Mute + Select Button	<ul style="list-style-type: none"> • Switch to bypass mode: When the main power is normal, press ON/Mute and Select buttons simultaneously for 5 seconds. Then UPS will enter to bypass mode. This action will be ineffective when the input voltage is out of acceptable range.

3.2 LCD Panel



Display	Function
Backup time information	
	Indicates the backup time in pie chart.
	Indicates the backup time in numbers. H: hours, M: minute, S: second
Fault information	
	Indicates that the warning and fault occurs.
	Indicates the warning and fault codes, and the codes are listed in details in 3-5 section.
Mute operation	
	Indicates that the UPS alarm is disabled.
Output & Battery voltage information	
	Indicates the output voltage, frequency or battery voltage. Vac: output voltage, Vdc: battery voltage, Hz: frequency
Load information	
	Indicates the load level by 0-25%, 26-50%, 51-75%, and 76-100%.
	Indicates overload.
	Indicates the load or the UPS output is short circuit.
Programmable outlets information	
	Indicates that programmable management outlets are working.

Mode operation information	
	Indicates the UPS connects to the mains.
	Indicates the battery is working.
	Indicates the bypass circuit is working.
	Indicates the ECO mode is enabled.
	Indicates the Inverter circuit is working.
	Indicates the output is working.
Battery information	
	Indicates the Battery level by 0-25%, 26-50%, 51-75%, and 76-100%.
	Indicates the battery is fault.
	Indicates low battery level and low battery voltage.
Input & Battery voltage information	
	Indicates the input voltage or frequency or battery voltage. Vac: Input voltage, Vdc: battery voltage, Hz: input frequency


3.3. Audible Alarm

Battery Mode	Sounding every 4 seconds
Low Battery	Sounding every second
Overload	Sounding twice every second
Fault	Continuously sounding
Bypass Mode	Sounding every 10 seconds

3.4. LCD display wordings index

Abbreviation	Display content	Meaning
ENA	ENR	Enable
DIS	di S	Disable
ESC	ESC	Escape
HLS	HLS	High loss
LLS	LLS	Low loss
BAT	bAt	Battery
CF	CF	Converter
EP	EP	EPO
FA	FR	Fan
TP	tP	Temperature
CH	CH	Charger

3.5 UPS Setting




There are three parameters to set up the UPS.


Parameter 1: It's for program alternatives. There are 9 programs to set up. Refer to the table.

Parameter 2 and parameter 3 are the setting options or values for each program.


01: Output voltage setting

Interface	Setting
	<p>Parameter 3: Output voltage For 208/220/230/240 VAC models, you may choose the following output voltage: 208: present output voltage is 208Vac 220: present output voltage is 220Vac 230: present output voltage is 230Vac 240: present output voltage is 240Vac</p>


02: Frequency Converter enable/disable

Interface	Setting
	<p>Parameter 2 & 3: Enable or disable converter mode. You may choose the following two options: CF ENA: converter mode enable CF DIS: converter mode disable</p>


03: Output frequency setting

Interface	Setting
	<p>Parameter 2 & 3: Output frequency setting. You may set the initial frequency on battery mode: BAT 50: present output frequency is 50Hz BAT 60: present output frequency is 60Hz</p> <p>If converter mode is enabled, you may choose the following output frequency: CF 50: present output frequency is 50Hz CF 60: present output frequency is 60Hz</p>


04: ECO enable/disable

Interface	Setting
	<p>Parameter 3: Enable or disable ECO function. You may choose the following two options: ENA: ECO mode enable DIS: ECO mode disable</p>


05: ECO voltage range setting

Interface	Setting
	<p>Parameter 2 & 3: Set the acceptable high voltage point and low voltage point for ECO mode by pressing Down key or Up key. HLS: High loss voltage in ECO mode in parameter 2. For 208/220/230/240 VAC models, the setting range in parameter 3 is from +7V to +24V of the nominal voltage. LLS: Low loss voltage in ECO mode in parameter 2. For 208/220/230/240 VAC models, the setting range in parameter 3 is from -7V to -24V of the nominal voltage.</p>


06: Bypass enable/disable when UPS is OFF

Interface	Setting
	<p>Parameter 3: Enable or disable Bypass function. You may choose the following two options: ENA: Bypass enable DIS: Bypass disable</p>


07: Bypass voltage range setting

Interface	Setting
	<p>Parameter 2 & 3: Set the acceptable high voltage point and acceptable low voltage point for Bypass mode by pressing the Down key or Up key. HLS: Bypass high voltage point For 208/220/230/240 VAC models: 230-264: setting the high voltage point in parameter 3 from 230Vac to 264Vac. LLS: Bypass low voltage point For 208/220/230/240 VAC models: 170-220: setting the low voltage point in parameter 3 from 170Vac to 220Vac</p>

08: Programmable outlets enable/disable







Interface	Setting
	<p>Parameter 3: Enable or disable programmable outlets. ENA: Programmable outlets enable DIS: Programmable outlets disable</p>

09: Programmable outlets setting

Interface	Setting
	<p>Parameter 3: Set up backup time limits for programmable outlets. 0-999: setting the backup time limits in minutes from 0-999 for programmable outlets which connect to non-critical devices on battery mode.</p>

00: Exit setting





















3.6. Operating Mode Description

Operating mode	Description	LCD display
Online mode	When the input voltage is within acceptable range, UPS will provide pure and stable AC power to output. The UPS will also charge the battery at online mode.	
ECO mode	Energy saving mode: When the input voltage is within voltage regulation range, UPS will bypass voltage to output for energy saving.	
Frequency Converter mode	When input frequency is within 40 Hz to 70 Hz, the UPS can be set at a constant output frequency, 50 Hz or 60 Hz. The UPS will still charge battery under this mode.	
Battery mode	When the input voltage is beyond the acceptable range or power failure and alarm is sounding every 4 second, UPS will backup power from battery.	
Bypass mode	When input voltage is within acceptable range but UPS is overload, UPS will enter bypass mode or bypass mode can be set by front panel. Alarm is sounding every 10 second.	
Standby mode	UPS is powered off and no output supply power, but still can charge batteries.	







3.7. Faults Reference Code


Fault event	Fault code	Icon	Fault event	Fault code	Icon
Fault code	01	X	Inverter voltage Low	13	X
Bus over	02	X	Inverter output short	14	SHORT
Bus under	03	X	Battery voltage too high	27	BATT. FAULT
Bus unbalance	04	X	Battery voltage too low	28	BATT. FAULT
Inverter soft start fail	11	X	Over temperature	41	X
Inverter voltage high	12	X	Over load	43	OVER LOAD

3.8. Warning indicator

Warning	Icon (flashing)	Alarm
Low Battery	 	Sounding every second
Overload	 	Sounding twice every second
Battery is not connected	 	Sounding every second
Over Charge	 	Sounding every second
Site wiring fault	 	Sounding every second
EPO enable	 	Sounding every second
Fan Failure	 	Sounding every second
Over temperature	 	Sounding every second
Charger failure	 	Sounding every second
Out of bypass voltage range	 	Sounding every second

If the UPS system does not operate correctly, please solve the problem by using the table below.

Symptom	Possible cause	Remedy
No indication and alarm even though the mains is normal.	The AC input power is not connected well.	Check if input power cord firmly connected to the mains.
	The AC input is connected to the UPS output.	Plug AC input power cord to AC input correctly.
The icon  and the warning EP code flashing on LCD display and alarm is sounding every second.	EPO function is activated.	Set the circuit in closed position to disable EPO function.
The icon  and  flashing on LCD display and alarm is sounding every second.	Line and neutral conductors of UPS input are reversed.	Rotate mains power socket by 180° and then connect to UPS system.
The icon  and  flashing on LCD display and alarm is sounding every second.	The external or internal battery is incorrectly connected.	Check if all batteries are connected well.
Fault code is shown as 27 and the icon BATT. FAULT is lighting on LCD display and alarm is continuously sounding.	Battery voltage is too high or the charger is fault.	Contact your dealer.
Fault code is shown as 28 and the icon BATT. FAULT is lighting on LCD display and alarm is continuously sounding.	Battery voltage is too low or the charger is fault.	Contact your dealer.
The icon  and OVER LOAD is flashing on LCD display and alarm is sounding twice every second.	UPS is overload	Remove excess loads from UPS output.
	UPS is overloaded. Devices connected to the UPS are fed directly by the electrical network via the Bypass.	Remove excess loads from UPS output.
	After repetitive overloads, the UPS is locked in the Bypass mode. Connected devices are fed directly by the mains.	Remove excess loads from UPS output first. Then shut down the UPS and restart it.
Fault code is shown as 43 and the icon OVER LOAD is lighting on LCD display and alarm is continuously sounding.	The UPS shut down automatically because of overload at the UPS output.	Remove excess loads from UPS output and restart it.
Fault code is shown as 14 and the icon SHORT is lighting on LCD display and alarm is continuously sounding.	The UPS shut down automatically because short circuit occurs on the UPS output.	Check output wiring and if connected devices are in short circuit status.

Symptom	Possible cause	Remedy
Fault code is shown as 1, 2, 3, 4, 11, 12, 13 and 41 on LCD display and alarm is continuously sounding.	A UPS internal fault has occurred. There are two possible results: 1. The load is still supplied, but directly from AC power via bypass. 2. The load is no longer supplied by power.	Contact your dealer
Battery backup time is shorter than nominal value	Batteries are not fully charged	Charge the batteries for at least 5 hours and then check capacity. If the problem still persists, consult your dealer.
	Batteries defect	Contact your dealer to replace the battery.
The icon  and the warning code <i>FR</i> flashing on LCD display and alarm is sounding every second.	Fan is locked or not working	Check fans and notify dealer.

Operation

The UPS system contains no user-serviceable parts. If the battery service life (3~5 years at 25°C ambient temperature) has been exceeded, the batteries must be replaced. In this case, please contact your dealer.

Storage

Before storing, charge the UPS 5 hours. Store the UPS covered and upright in a cool, dry location.

During storage, recharge the battery in accordance with the following table:

Storage Temperature	Recharge Frequency	Charging Duration
-25°C - 40°C	Every 3 months	1-2 hours
40°C - 45°C	Every 2 months	1-2 hours

MODEL		PH 9310	PH 9315	PH 9320	PH 9330
CAPACITY *		1000 VA / 900W	1500 VA / 1350 W	2000 VA / 1800 W	3000 VA / 2700 W
INPUT					
Voltage Range	Low Line Transfer	160 VAC/140 VAC/120 VAC/110 VAC± 5 % (based on load % carga: 100% - 80 % / 80 % - 70 % / 70 - 60 % / 60 % - 0)			
	Low Line Comeback	170 VAC/150 VAC/130 VAC/120 VAC ± 5 %			
	High Line Transfer	150 VAC ± 5 % or 300 VAC ± 5 %			
	High Line Comeback	145 VAC ± 5 % or 290 VAC ± 5 %			
Frequency Range		45 Hz ~ 55 Hz or 56 Hz ~ 65 Hz			
Phase		Single phase with ground			
Power Factor		≥0.99 @ 200-230VAC o 100-120VAC			
OUTPUT					
Output voltage		200/208/220/230/240 VAC			
AC Voltage Regulation (Batt. Mode)		± 1%			
Frequency Range (Synchronized Range)		48 Hz ~ 52 Hz or 58 Hz ~ 62 Hz			
Frequency Range (Batt. Mode)		50 Hz ± 0.2 Hz or 60 Hz ± 0.3 Hz			
Current Crest Ratio		3:1			
Harmonic Distortion		≤2 % THD (linear load) ≤8 % THD (Bat mode before shut down)			
Tempo trasfer	AC Mode to Batt. Mode	Zero			
	Inverter to Bypass	4 ms (Typical)			
Waveform (Batt. Mode)		Pure Sinewave			
EFFICIENCY					
AC Mode		~ 90%		~ 91%	
Battery Mode		~ 89%		~ 89%	
BATTERY					
Standard Model	Battery Type	12 V / 9 AH	12 V / 9 AH	12 V / 9 AH	12 V / 9 AH
	Numbers	2	4	6	6
	Recharge Time	4 hours recover to 90% capacity (Typical)			
	Charging Current	1.0 A(max.)			
	Charging Voltage	27.4 VDC ± 1%	54.8 VDC ±1%	82.1 VDC ±1%	82.1 VDC ±1%
PHYSICAL					
Tower	Dimension, Pr X An X Al	410 x 437 x 84 (mm)	512 x 437 x 84 (mm)	630 x 437 x 84 (mm)	630 x 437 x 84 (mm)
	Net Weight (kg)	16	29	31	31
ENVIRONMENT					
Operation Humidity (non-condensing)		20-90 % RH @ 0- 40°C			
Noise Level		< 50dBA @ 1 meter			
MANAGEMENT					
Smart RS-232 or USB		Supports Windows® 98/2000/2003/XP/Vista/2008/ 7, Linux, Unix and MAC			
Optional SNMP		Power management from SNMP manager and web browser			

* Derate capacity to 60% of capacity in Frequency converter mode and to 80% when the output voltage is adjusted to 200/208VAC.